

MANUFACTURING DEFECTS QUALITY CONTROL ANALYSIS



INTRODUCTION

Quality Control helps make sure that products are **made correctly** and **meet the required standards**. It includes steps to check each stage of production from the start to the final check so that any problems can be found early. This reduces waste, keeps product quality consistent, and improves the overall process. In this project, we used a defect sampling method, where one item is **randomly checked every 15 minutes during an 8-hour shift** (about 22–24 samples per shift). This helps us spot small or major defects early. We also **used control charts** to track how stable the process is. With these tools, we can make sure products meet quality standards and keep improving the process over time.

OBJECTIVES

- To evaluate the **frequency and distribution of minor defects** observed across ten days of production.
- To identify potential areas for **process improvement**, supporting **consistent quality** and **defect reduction**.
- To assess the stability and variability of the manufacturing **process using statistical process control techniques**

METHODOLOGY

Preliminary Check

We used the Anderson–Darling test to check if defect data followed a **normal pattern**. Since the **p-value was below 0.005**, the data was suitable for **control chart analysis**.

Phase I – Start-Up Stage

- We applied a **c-chart** to check if the process was stable.
- Sample Plan: 224 items were sampled over 10 days (one every 15 minutes during 8-hour shifts).

Phase II – Mass Production

- Sample Plan: 96 more items will be checked.
- Monitoring: The **same control limits from Phase I will continue to be used**.

Process Capability


- Pp: Measures how wide the **process spread** is compared to the **limits**.
- Ppk: Shows how well the **process is centered** within those limits.

SOURCE : KAGGLE




SCAN ME

RESULTS



PHASE 1

The C-chart shows no points outside the control limits indicating the **process in control**




PHASE 2

The C-chart shows no points outside the control limits indicating the **process in control**

Process Capability Report for Parts Defects(Phase I)

Process Capability Report for Parts Defects(Phase I)




PROCESS CAPABILITY PHASE 1

USL: 25 LSL: 0
Cp = 1.21, Cpk= 0.99
the process appears stable but **off centre**

The actual process spread is represented by 6 sigma.

Process Capability Report for Parts Defects(Phase II)



PROCESS CAPABILITY PHASE 2

USL: 25 LSL: 0
Cp= 1.39, Cpk=1.17
The process appears stable but **off centre**

CONCLUSION

- The defect data is normally distributed, suitable for control chart analysis.
- All points in Phase I & II C-Charts are within control limits → the process is stable.
- No abnormal trends or patterns detected - defects are likely random.
- Process capability indicates low variation and consistent quality output.

RECOMENDATION

- Continue monitoring using C-Charts to maintain process stability.
- Investigate immediately if future points fall outside control limits.
- Strengthen machine maintenance and operator training to prevent issues.
- Use control chart findings to continuously improve product quality.

GROUP MEMBER



SITI SYUHAIRA BINTI
SHAIFOL RIZAL
AW230032



MUHAMMAD HAFIZ
BIN ABDUL HALIM
AW230003



KHAIRUNNISA SYAFIQAH
BINTI MOHD EFENDI
AW230025



CHONG JIA YOU
AW230232

MANUFACTURING DEFECTS QUALITY CONTROL ANALYSIS



CHONG JIA YOU
AW230232



KHAIRUNNISA SYAFIQAH
BINTI MOHD EFENDI
AW230025



SITI SYUHAIRA BINTI
SHAIFOL RIZAL
AW230032



MUHAMMAD HAFIZ
BIN ABDUL HALIM
AW230003

GROUP MEMBER

INTRODUCTION

Quality Control helps make sure that products are **made correctly** and **meet the required standards**. It includes steps to check each stage of production from the start to the final check so that any problems can be found early. This reduces waste, keeps product quality consistent, and improves the overall process. In this project, we used a defect sampling method, where one item is **randomly checked every 15 minutes during an 8-hour shift** (about 22–24 samples per shift). This helps us spot small or major defects early. We also **used control charts** to track how stable the process is. With these tools, we can make sure products meet quality standards and keep improving the process over time.

OBJECTIVES

- To evaluate the **frequency and distribution of minor defects** observed across ten days of production.
- To identify potential areas for **process improvement**, supporting **consistent quality** and **defect reduction**.
- To assess the stability and variability of the manufacturing **process using statistical process control techniques**

RESULTS

METHODOLOGY

Preliminary Check

We used the Anderson–Darling test to check if defect data followed a **normal pattern**. Since the **p-value was below 0.005**, the data was suitable for **control chart analysis**.

Phase I – Start-Up Stage

- We applied a **c-chart** to check if the process was stable.
- Sample Plan: 224 items were sampled over 10 days (one every 15 minutes during 8-hour shifts).

Phase II – Mass Production

- Sample Plan: 96 more items will be checked.
- Monitoring: The **same control limits from Phase I will continue to be used**.


Process Capability

- Pp: **Measures** how wide the **process spread** is compared **to the limits**.
- Ppk: Shows how well the **process is centered** **within those limits**.

SOURCE : KAGGLE




SCAN ME




PHASE 1

The C-chart shows no points outside the control limits indicating the **process in control**




PHASE 2

The C-chart shows no points outside the control limits indicating the **process in control**



PROCESS CAPABILITY PHASE 1

USL: 25 LSL: 0
Cp = 1.21, Cpk= 0.99
the process appears stable but **off centre**



PROCESS CAPABILITY PHASE 2

USL: 25 LSL: 0
Cp= 1.39, Cpk=1.17
The process appears stable but **off centre**

CONCLUSION

- The defect data is normally distributed, suitable for control chart analysis.
- All points in Phase I & II C-Charts are within control limits → the process is stable.
- No abnormal trends or patterns detected - defects are likely random.
- Process capability indicates low variation and consistent quality output.

RECOMENDATION

- Continue monitoring using C-Charts to maintain process stability.
- Investigate immediately if future points fall outside control limits.
- Strengthen machine maintenance and operator training to prevent issues.
- Use control chart findings to continuously improve product quality.